



Instructions for packing the Hillbilly Gas Camp Oven Kit into the carry bag

For easy fitting of the complete Hillbilly Gas Camp Oven Kit into the canvas carry bag just follow the steps below

1. Place the carry bag on a flat surface with the cover flap open and laying toward you
2. Sit the base of the oven onto opening flap of the camp oven bag
3. Leave the Baking Trivet and Vegetable Cooking Ring inside the base of oven
4. Turn Gas Burner over so the gas ring is facing upwards and sit the burner face up into the camp oven base
5. Place the Cooktop Rack over the burner with the legs of the rack facing down
6. Turn the oven lid upside down and lay over the top of the Gas Burner, (so there is a smooth surface on the top and the lip of the lid is facing downwards)
7. Slide the whole unit into the Camp Oven Bag and place the handle of the oven around the base in the bag.

